

Operating Instructions Manual

Read through this owner's manual carefully before using the product. Protect yourself and others by observing all safety information, warnings, and cautions. Failure to comply with instructions could result in personal injury and/or damage to product or property. Please retain instructions for future reference.

87-1510 1/4" MINI RIGHT ANGLE DIE GRINDER



Specifications:

Model	Speed +/- 10% (RPM)	Air Inlet NPT (in.)	Required Pressure (psi)	Weight (lbs)
87-1510	15,000	1/4	90	0.86

General Safety Information

This manual contains information that is very important to know and understand. This information is provided for SAFETY and to PREVENT EQUIPMENT PROBLEMS. To help recognize this information, observe the following symbols.

A CAUTION | Caution indicates a potentially hazardous situation which, if not avoided, will result in death or serious injury.

AWARNING Warning indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

A DANGER Danger indicates and imminently hazardous situation which, if not avoided, will result in death or serious injury

NOTICE Notice indicates important information that, if not followed, may cause damage to equipment.

Entanglement Hazards

Keep away from rotating drive.

A CAUTION Do not wear jewelry or loose clothing.

Choking can occur if neckwear is not kept away from the tool and accessories.

Scalping can occur if hair is not kept away from the tool and accessories.

Avoid direct contact with accessories during use. Use only proper accessories designed for use with pneumatic screwdrivers, nut runners, impacts, ratchets, grinders, drills, and pulse tools.

Projectile Hazards

Always wear impact-resistant eye and face protection when involved with or near the operation, repair or maintenance of the tool or changing accessories on the tool.

Be sure all others in the area are wearing impactresistant eye and face protection.

A DANGEREven small projectiles can injure eyes and cause blindness.

Workplace Hazards

AWARNING Slip/Trip/Fall is a major cause of serious injury or death. Beware of excess hose left on the walking or work surface.

High sound levels can cause permanent hearing loss. Maintain a balanced body position and secure footing. Repetitive work motions, awkward positions and exposure to vibration can be harmful to hands and arms.

Operators and maintenance personnel must be physically able to handle the bulk, weight and power of this tool.

Installation

Designed to operate on 90 PSI, lower pressure (below 90 PSI) will reduce performance of the tool while higher air pressure (over 90 PSI) raises the performance of the tool beyond its rated capacity and could cause serious damage to tool and user.

AWARNING Always use clean dry air. Excessive moisture and dirt will greatly reduce the life of any air motor.

We recommend the installation of an inline filter-regulatorlubricator as close to the tool as possible.

Operation

Supply tool with 90 PSI of clean, dry air. Higher pressure drastically reduces tool life. However, line pressure should be increased to compensate for unusually long hoses (over 25ft). Minimum hose size should be ¼" in diameter with fittings having the same inner diameters.

Air Supply and Connection Hazards

Air under pressure can cause severe injury.


Always shut off air supply, drain hose of air pressure and disconnect tool from air supply when not in use, before changing accessories or when making repairs.

Never direct air at yourself or anyone else.

Whenever universal twist couplings are used, lock pins must be installed.

A CAUTION Do not exceed maximum air pressure of 90 PSI.

Water in the airline will cause damage to the tool. Drain air tank daily. Clean the air inlet filter screen on a weekly basis. The recommended hook up procedure is below:



Lubrication

Use an airline lubricator, two drops per minute. If an air line lubricator cannot be used, add air motor oil to the inlet once a day, or more frequently for extended use.